SONY CFS-DW38L SCHEMATIC DIAGRAM (Audio Section)

Note: Design and specifications subject to change without notice



Ref NO.	NAME	MODE	POSITION
S301	FUNCTION	LINE-RADIO-DUBBING-TAPE	LINE
S302	REC/P·B	REC-P·B	P·B
S303	ISS/MO-ST	1-2, ST-MO	1, ST
S401	MD-A ON	ON-OFF	OFF
S402	HI-SPEED ON	ON-OFF	OFF
S403	MD-B ON	ON-OFF	OFF
S404	MD-B P·B ON	ON-OFF	OFF

Printed in Malaysia